How to Care for Your Butane Lighter

Bleeding and Filling

- 1. Bleed your lighter each time you refill it.
- 2. Release all tank pressure by pressing on the inlet valve with a small screwdriver or a XIKAR MTX Multi Tool bleeder (shown). Hold the lighter upside down while bleeding valve and repeat until all fuel/gas pressure is released.
- 3. Holding upside down, insert butane tank tip directly on the fuel valve. Press down firmly for about 5 seconds.
- 4. Before igniting lighter, wait 3-4 minutes for excess butane to evaporate and butane inside lighter to reach room temperature.
- 5. Set flame level to desired height by turning flame adjuster wheel.







Buy with confidence!

All XIKAR lighters carry an unconditional lifetime warranty.



Extinguishing the Flame

- Releasing pressure from the ignition button of the lighter immediately extinguishes the flame.
- If flame continues, the flame level is set too high and should be adjusted by turning adjustment wheel on the bottom of the lighter towards the (-) position.

Filling and Re-filling Your Lighter

- · Bleeding and adjusting your lighter is much easier with a XIKAR MTX Multi-tool!
- Lighter contains flammable gas under pressure. Handle carefully.
- · Ensure that flame is extinguished before attempting to fill.
- · Never ignite lighter while refilling.
- Read butane canister warning labels.
- Only refill lighter in a well-ventilated area.
- Hold lighter away from face and clothing
- Never fill lighter around any heat source,
- Premium butane, such as XIKAR brand butane, with near 0 impurities is highly recommended, as lower quality butane has

been known to clog lighters.

Caring for Your Lighter

Lighters not in use / Lighters in storage

• Before storing lighters, empty all fuel.

Cleaning your Lighter

· To clear obstructions such as dirt or lint, blow a burst of air into the ignition valve.

Everyday storage of your lighter

· To prevent scratching your lighter we recommend you keep it in a XIKAR register your warranty at www.xikar.com

For best results, use XIKAR PUROFINE™



Any Questions? Contact Us

Phone:

E-mail: info@xikar.com

Letter:

866-676-7380 PO BOX 025757

Kansas City, MO 64102-5757 www.xikar.com